Bluetooth Only RGB / Multi-Function
# Wireless LED GEN 1 Controller

BLRC-003, BLRC-003+ (with and without brake flash), BLRC-003S, BLRC-008

Controller RED (or WHITE) Wire
Connects to positive side of battery

Controller Black Ground Wire
Connects to negative side of battery.

12V Battery

NOTE: The RESET button erases any preset options and controller named settings in the APP.

PLEASE NOTE:
Controller and power adapter (if used) is water resistant but NOT waterproof. Be sure to mount in a dry location.

In-line Fuse Holder

LED Strip Blue, Red, Green & Black Wires
Connects w/ Red, Green, Blue and Black Wires from Controller. Connect with an orange Posi-Twist. Each wire represents its respective light color. Black is the Ground wire.

Optional 110vac Power Converter

110VAC APPLICATIONS

If you are using the optional 110VAC power adapter instead of 12vdc power, you would connect the POSITIVE wire coming from the 110VAC power adapter to the POSITIVE wire of the controller. Connect the NEGATIVE wire coming from the 110VAC power adapter to the black wire of the controller (which is the ground wire). Then, plug in the 110VAC power adapter cable into your 110VAC power source.

RESET

Controller

[BLRVWDMCABT 071916]

RULE THE NITE ™
Boogey Lights ®
Motorsports Accent Lighting Since 1989!

800.847.1359

www.BoogeyLights.com