

# RV Awning Kit Wiring Diagram

## Multi-Function Wireless RF Controller



**PLEASE NOTE:**  
Controller and power adapter (if used) is water resistant but NOT waterproof. Be sure to mount in a dry location.

### 110VAC APPLICATIONS

If you are using the optional 110VAC power adapter instead of 12vdc power, you would connect the POSITIVE wire coming from the 110VAC power adapter to the POSITIVE wire of the controller. Connect the NEGATIVE wire coming from the 110VAC power adapter to the black wire of the controller (which is the ground wire). Then, plug in the 110VAC power adapter cable into your 110VAC power source.

800.847.1359

RULE THE NITE™  
**BOOGEY LIGHTS**  
Lighting Bikes Since 1989!

[BLRVWDMCARF 081219]

www.BoogeyLights.com