

Family Owned Motorsports Lighting Since 1989!

# **INSTALLATION GUIDE**

# FREIGHTLINER CASCADIA GEN2 UNDER-GLOW LED LIGHT KIT

IMPORTANT! No two installation scenarios are the exact same. Accent lighting is highly subjective. Not everyone shares the same lighting or installation quality goals. Some folks are OK with twisting wires together, others want to solder and heat shrink them. Some folks are OK with running wires where they may be seen or unprotected to save money/time, others want a tidy, clean install so they wrap plastic split-loom around all exposed cables. Some folks are OK with mounting their LED strips to whatever surface they can find, others want to take the time necessary to build out appropriate mounting surfaces to provide the best lighting effect on their vehicle and maximize the longevity of their lighting system. The point is it's not possible to provide all the materials necessary for all installation scenarios on all types of vehicles to meet everyone's quality and lighting coverage goals. Our light kits provide the essential components needed for a high-quality, functioning LED light system. Installation of our light kit to your specific vehicle will however likely require additional items to make it look, fit and work the way you want. This is particularly the case with electrical wiring, switching functionality and mounting surfaces for the LED strips. We have created a list of additional items you may need. Here's the link: <a href="https://www.boogeylights.com/other-items-you-might-need/">https://www.boogeylights.com/other-items-you-might-need/</a>. While we offer them for sale you can also find these items locally — usually less expensive. We urge you to review this information before starting your install to make sure you have the proper materials available.

#### **BENCH TEST YOUR LIGHTING COMPONENTS FIRST!**

We know this takes a few extra minutes, but we STRONGLY suggest you bench test your lights AND your controller / switches on a table before doing anything further. Test all of them. While we test every light strip and controller before shipping, bench testing your lights will eliminate the possibility of any problems with the lights or controller before mounting. It also lets you know everything is working properly. Also, the process of bench testing gives you an opportunity to understand the wiring system without interference from other wires, connectors and cables. You can use any good 12vdc battery to do this (e.g. car battery, motorcycle battery, lawn tractor battery or 12vdc power supply capable of supporting a 5 amp load). If you're not sure how to do this, we have prepared a document explaining the process here: <a href="https://docs.boogeylights.net/?wpdmdl=1305">https://docs.boogeylights.net/?wpdmdl=1305</a>. Bench testing takes an extra 10 or 15 minutes. It's simple to do and can potentially save you hours of time and frustration down the road.

Did we mention the importance of bench testing every LED strip and controller before installing?


# **BEFORE YOU START**

THIS IS A GUIDE. NOT A HOW-TO. It's simply not possible to provide detailed instructions for all installation scenarios. Far too many variables. The information in this manual is intended to be used as a guide. It is not a detailed step-by-step how-to installation manual. We do not spell out every single step along the way. We cover the essential steps related to installing this kit. Beyond that we assume the installer has the skills, knowledge and tools necessary to do the work using the information we provide as a guide. You may need to vary your installation and/or make adjustments based on your truck. This is particularly the case with electrical wire routing, electrical connections, electrical load sizing and switching. If you're unsure about how to do the installation – particularly the electrical components – we urge you to seek assistance from someone who has those skills.

YOU MUST HAVE AN UNDERSTANDING OF 12V POWER. An essential skill with installation of any Boogey Lights LED products is knowing how to correctly wire the product to a 12vdc circuit. This includes understanding the importance of having a properly sized fuse at the power source, polarity, how to properly seal an electrical connection, using properly sized wire gauge for the load, measuring voltage and measuring the additional amperage draw you're adding. If you are uncertain or unfamiliar with any of these concepts, we urge you to ask someone who has the knowledge to assist you. Electricity is unforgiving.

**WORK AREA.** Make sure you have ample area in which to work and that the area is protected from rain or cold temperatures. The 3M adhesive tape and 3M adhesion promoter works best if applied when the air temperature is above 40 degrees (and of course is DRY).

**KNOW YOUR AMPERAGE DRAW.** Pay attention to the number of LEDs you are lighting and the total amps you will be drawing. We manufacture a number of LED Controllers of varying capacities. If you over-load the LED controller, it will either not work at all or the lights will dim in a short period of time. Amperage data for all our LED products are on each product page. You can also download it directly here: <a href="https://docs.boogeylights.net/?wpdmdl=1137">https://docs.boogeylights.net/?wpdmdl=1137</a>



## TYPICAL LED PLACEMENT

These are the LED placement locations we used for this kit. It's important to follow this placement pattern to ensure the LED strips are protected. We include some photos at the end of the guide showing further details.

# Front Bumper Area (left to right):

- 1 15 LED strip under the bumper
- 1 45 LED strip under the bumper
- 1 15 LED strip under the bumper

#### **Driver's Side (front to rear):**

- 1 15 LED strip in wheel well
- 1 45 LED strip mounted on plastic flat bar secured to outside air tank under steps
- 1 75 LED strip mounted on plastic flat bar secured to bottom of fuel tank
- 1 15 LED strip mounted to frame structure (e.g. storage box) behind fuel tank. Note: Not all trucks will have this area available to mount to.
- 1 75 LED strip mounted to top frame rail shining downward.
- 1 45 LED strip mounted to top frame rail shining downward (between the air bags).

## Passenger's Side (front to rear):

- 1 15 LED strip in wheel well
- 1 30 LED strip mounted under step structure.
- 1 75 LED strip mounted on plastic flat bar secured to bottom of fuel tank
- 1 15 LED strip mounted to frame structure (e.g. APU behind fuel tank.) Note: Not all trucks will have this area available to mount to.
- 1 60 LED strip mounted to top frame rail shining downward.
- 1 45 LED strip mounted to top frame rail shining downward (between the air bags).

#### Rear:

• 1 - 30 LED strip across the back bumper. Note: Not all trucks will have this area available.

#### **LED STRIP MOUNTING**

Follow these steps for mounting your LED strips:

- The area where you are mounting the LEDs has to be clean: free of all dirt, oil or anything that might affect the LED from sticking. You only get one opportunity to mount the LEDs so it's critical the area be prepared properly.
- Use the supplied alcohol pads to clean the area where you are going to mount the LED strip. Be sure to let the alcohol dry completely before proceeding to the next step. (Note: Do not use acetone or similar cleaner).
- Next, use the 3M Adhesion Promoter supplied with your kit to "paint" on the promoter where you are going to mount the LED strip. *This is an important step. Do not bypass.* Allow the promoter to dry for 60-90 seconds.
- Peel off the red backing tape that protects the 3M adhesive tape on your LED strip. Be careful not to let the tape touch anything. The 3M backing tape on these LED strips are one-use only. They cannot be reused.

Do NOT bend the LED strip in a radius of less than 2 inches.




Do NOT bend the LED strip on a horizontal plane.




• Carefully push the LED strip to the area you have prepared. You will want to apply only enough pressure to the strip to make sure it is firmly mounted. You only get one opportunity to do this. Once the LED strip touches a properly prepared surface that has been promoted, that LED strip will be very difficult to remove. Moreover, if you do remove the LED strip, the strip cannot be used again without adding another layer of 3M adhesive tape to the back. DO NOT press too hard as too much pressure can damage the LEDs and connecting wires in the strip. Also, do not pull, stretch or twist the LED strip. Too much tension on the strip will also damage the LEDs such that some of the LEDs in the strip will not illuminate. The strip must be mounted flat against a single continuous mounting surface, in a straight line. Really important that the ENTIRE STRIP be stuck to the mounting surface and that you NOT attempt to span across multiple mounting surfaces.

#### **INSTALLATION PHOTOS**


These photos make reference to some ALUMINIMUM FLAT BAR. That is not always the case. We include PLASTIC FLAT BAR instead of the aluminum flat bar. The plastic flat bar should be mounted the same way as the aluminum with one exception when mounting to the bottom of the fuel tanks: make sure the plastic flat bar is securely fastened to the fuel tank in multiple places across the entire length of the flat bar (not just on the two ends as some of the photos show). The goal is to minimize the amount of flexing the plastic flat bar does.






















#### **Additional Resources**

- How to Videos: <a href="https://www.boogeylights.com/how-to-videos/">https://www.boogeylights.com/how-to-videos/</a>
- Freightliner Cascadia Light Kit Page: <a href="https://www.boogeylights.com/freightliner-cascadia-led-accent-light-kit/">https://www.boogeylights.com/freightliner-cascadia-led-accent-light-kit/</a>
- Troubleshooting: <a href="https://www.boogeylights.com/trouble-shooting-guide/">https://www.boogeylights.com/trouble-shooting-guide/</a>
- Installation Resources: <a href="https://www.boogeylights.com/installation-resources/">https://www.boogeylights.com/installation-resources/</a>
- How to Bench Test: https://docs.boogeylights.net/?wpdmdl=1305
- GEN2 LED Controller Wiring Diagrams + Operating Info: <a href="https://docs.boogeylights.net/?wpdmdl=1163">https://docs.boogeylights.net/?wpdmdl=1163</a>
- GEN2 RF Wireless Remote Operating Info: <a href="https://docs.boogeylights.net/?wpdmdl=1164">https://docs.boogeylights.net/?wpdmdl=1164</a>
- GEN2 Bluetooth APP Operating Info: https://docs.boogeylights.net/?wpdmdl=1169
- GEN2 Bluetooth APP Quick-Start: https://docs.boogeylights.net/?wpdmdl=1167
- Amperage Data: https://docs.boogeylights.net/?wpdmdl=1137

# **Support**

- Phone: 800.847.1359 (M-F, 9-6 Eastern)
- Text: 859.955.8155
- Open a Support Ticket: <a href="https://www.boogeylights.com/email-us/">https://www.boogeylights.com/email-us/</a>
- Online: 24/7 resources at https://www.boogeylights.com/installation-resources/
- How to Make a Warranty Claim: https://www.boogeylights.com/make-a-warranty-claim/

#### Warranty

The Boogey Lights® warranty requires an original sales receipt from Boogey Lights or an authorized dealer. It covers product replacement only, not labor or other costs. Register your purchase at: <a href="https://www.boogeylights.com/warranty/">https://www.boogeylights.com/warranty/</a>. Full details: <a href="https://www.boogeylights.com/warranty/">https://www.boogeylights.com/warranty/</a>.